



6.5 percent

4 percent

5 percent

8 1/2 inches

3 inches

3 percent

5 1/2 inches

0 inches

The three distinct benchwork sections are bound together by 1 x 4-foot link sections that can be removed to access a window or placed behind a bed when the layout isn't in use

0 inches

3 inches

To simulate the harvest of timber from the forest, install a couple of Lionel no. 14145 operating lumberjacks accessories in this section of your layout. CTT Expert Contributor Peter Riddle shared his tips for hiding accessory bases in the December 2005 issue of CTT

10 inches

A removable tail track doesn't have to be much more than track mounted to a 2 x 4 pine board to serve as a link to a mainline railroad that adds or removes cars. When the room door is closed, the board sets on brackets fixed to the layout and wall. When you need to open the door, one or more 2 x 4s with cars will store neatly under the layout

K-Line no. K42450 operating sawmill is a fairly compact accessory that provides a destination for the most common freight on the railroad

A working log pond for this area of the layout comes easily if you have an operating log car and a section of Atlas O 6059 uncoupling track

MTH no. 30-11028 operating water tower features scale details that make it a focal point on the railroad, as well as an essential stop for steam locomotives

2 1/2 inches

2 1/2 inches

2 1/2 inches